

Cubicle Bracket Installation Instructions



Part list:

- (2) Left side L Brackets
- (2) Right side L Brackets
- (2) Clamp Brackets
- (2) Screws
- (2) Bolts



Step 1

Attach the first clamp bracket to a right and left side 'L' bracket with the screw using the top hole.



Step 2

Attach the second clamp bracket to a right and left side 'L' bracket with the screw using the top hole.



Step 3

There will be a left and right side bracket.



Step 4

Open the mouth of the assembled bracket and place over the existing wall. Pinch together until firm hold on the wall and tighten the screw. Place roughly 4"-8" from the edge of the existing panel. Repeat process for the second bracket.



Step 5

Place the screen in between the mouth of the clamp bracket and tighten down using the provided bolt.