



Frosted Acrylic Stackers - adjustable mounting with radius corners

CUBICLE EXTENDER PANELS

Add visual and sound privacy to your existing cubicles with Stackers™. Our cubicle extender panels are a cost-effective solution to add height to existing cubicle walls while updating the look and adding visual interest to your office.

Stackers Panel Model Styles:

- Stackers Panel** - radius corners on all sides, bottom edge of panel sits 1/2" off workstation. Mounting location is adjustable.
- Stackers Flush Mount** - set mounting locations on Stackers Panel with no gap fit on top of workstation. Stacker styles available with 90° corners on bottom or radius corners on top or with 90° corners on all four sides.
- Stackers Flush Mount for Glass Workstation Panels** - set mounting locations with Double Square Mounts to stack on top of glass workstation panels
- Stackers Invisible Mount** - permanently mounted, the panel slides over the mount through a slit on the underside of the panel. Once complete, the mount is invisible.
- Permanent and removable mounting options
- Mounting options for flat workstation top caps:
 - Permanent Mount - Square or Tower Mount
 - Magnetic Mount - Up to 24"h
 - Adhesive Removable Mount - Up to 24"h
 - Medium Clamp-On Mount – adjusts to fit workstation top caps 1.9"-3.0"
 - Large Clamp-On Mount – adjusts to fit workstation top caps 2.9"- 4.0"
 - Invisible Mount - EchoScape - 3/4" (18mm) only
 - Invisible Adhesive Mount - EchoScape - 3/4" (18mm) only
- Mounting options for curved workstation top caps:
 - Permanent Mount - Square Mount
 - Medium Clamp-On Mount – adjusts to fit workstation top caps 1.9"-3.0"
 - Large Clamp-On Mount – adjusts to fit workstation top caps 2.9"- 4.0"
- Mounting options for glass or acrylic workstation panels:
 - Removable Double Square Mount

- Stackers can be mounted on most workstations or cubicles
- Frosted or Clear Acrylic - 0.25" thick with polished edges
- Acoustic EchoScape™ effectively controls noise by absorbing sound:
 - 3/8" (9mm) and 3/4" (18mm) thickness
 - NRC rated up to 0.9
- Multiple panel sizes available to match your cubicle or workstation dimensions



Acoustic EchoScape™ Stackers with Invisible Mount

How to build your SKU:

Step 1: Choose your Model	Step 2: Choose your Style	Step 3: Choose your Width	Step 3: Choose your Height	Step 4: Choose your Material Color	Step 5: Banner Cutout Design (optional) (EchoScape Styles only)	Step 6: Choose your Mounting Option
STK	PE18	54	16	P102	D005	STW2

STACKERS™

Model	Style	Width	Height *	Material Color	Banner Cutout Designs (optional) (EchoScape Styles only)	Mounting Options			
STK	Stackers™ original mount with radius corners on all panel sides	FRO	Frosted Acrylic	24"	12"	P1_ EchoScape™	D002 Fizzy	STW	Tower Mount
		CLR	Clear Acrylic	30"	16"		D004 Metro	STW.R	Tower Adhesive Mount
STKN	Stackers™ Flush Mount with 90° corners bottom and radius corners top	PE18	EchoScape™ 3/4" (18mm)	36"	18"		D005 Dash	STW.M	Tower Magnetic Mount
		IPE18	EchoScape™ 3/4" (18mm) Invisible Mount	42"	24"		D008 Tribal	STW.CM	Tower Medium Clamp-On Mount
STKNS	Stackers™ Flush Mount with 90° square corners on all panel sides	PE9	EchoScape™ 3/8" (9mm)	48"	30"		D016 Retro	STW.CL	Tower Large Clamp-On Mount
				54"			D016 Strata	SSQ	Square Mount
STGS	Stackers™ Flush Mount to attach to existing glass workstation panels-90° panel corners			60"			D016 Maze	SSQ.R	Square Adhesive Mount
				66"			D016 Aztec	SDSQ	Double Square Mount
				72"			D016 Pinwheel	SIM	Invisible Mount
								SIM.R	Invisible Adhesive Mount

* Flush Mount Panels are 0.05" shorter

Stackers (STK)

Stackers panels have 4 radius corners and are available with both permanent and removable mounting options. The clamp position on Stackers is adjustable to fit your needs. When mounted the Stacker panel sits 1/2" above the top workstation or cubicle panel.



Material choices for Stackers include Clear and Frosted Acrylic and acoustic EchoScape™ in both 3/8" (9mm) and 3/4" (18mm) thicknesses. Multiple permanent and removable mounting options are available with Stackers.



Stackers Panel (STK-FRO)




Stackers Panel (STK-PE9)




Stackers Flush Mount (STKN and STKNS)

Stackers Flush Mount panels have inset mounting locations on the panels for a flush mount with the workstation or cubicle. The no-gap panel bottom has 90° corners to maintain a seamless fit between the top of the workstation and the bottom of the Stackers panel. To complete your look, Flush Mount Stackers can be ordered with either radius or 90° top corners.

Material choices for Stackers Flush Mount include Clear and Frosted Acrylic and acoustic EchoScape™ in both 3/8" (9mm) and 3/4" (18mm) thicknesses. Multiple permanent and removable mounting options are available with the Stackers Flush Mount model.




Stackers Flush Mount Panel (STKN-FRO)
with radius top corners







Stackers Flush Mount Panel (STKNS-FRO)
with 90° square corners



Stackers Flush Mount Panel (STKN-PE9)
with radius top corners





Stackers Flush Mount Panel (STKNS-PE9)
with 90° square corners




Stackers Flush Mount for Glass Workstation (STGS)

Extend the height of existing glass or acrylic workstations with our Stackers Flush Mount in Clear or Frosted Acrylic or acoustic EchoScape™ materials. Mounted, with our secure Double Square Mounts, this removable solution is easy to install and adds protection and height without having to remove glass panels.



Stackers Flush Mount for Glass Workstation (STGS-FRO)



Stackers Flush Mount for Glass Workstation (STGS-PE9)



Stackers Flush Mount for Glass Workstation (STGS-FRO)



Tower Mount (STW)

- For use with Clear & Frosted Acrylic and all acoustic EchoScape™ Panels
- Permanent mount - Screw down
- For use on a flat panel top cap
- Minimum top cap width - 1.50"
- Kits include 2 or 4 Tower Mount kits depending on width of panel
- Use with Stackers and Stackers Flush Mount



Tower Adhesive Mount (STW.R)

- For use with Clear & Frosted Acrylic and 3/8" (9mm) acoustic EchoScape™ panels
- Removable adhesive strips are used to attach metal plate to flat workstation top cap
- Adhesive mounts and strips can easily be removed with no damage to the top cap
- Minimum top cap width - 1.625"
- Kits include 2 or 4 Tower Mount kits depending on width of Stacker panel
- Use with Stackers and Stackers Flush Mount



Tower Magnetic Mount (STW.M)

- For use with Clear & Frosted Acrylic and 3/8" (9mm) acoustic EchoScape™ panels
- Removable Magnet Mount is made from neodymium magnet
- Magnet Mount for installation on flat workstation top cap
- Minimum top cap width - 1.50"
- Kits include 2 or 4 Tower Mount kits depending on width of Stacker panel
- Use with Stackers and Stackers Flush Mount



Tower Medium Clamp-On Mount (STW.CM)

- For use with Clear & Frosted Acrylic and all acoustic EchoScape™ panels
- For use on flat or curved workstation top cap
- Removable adjustable tension mount fits workstation top caps 1.9" – 3.0" in width
- Tower Mount attaches and holds the clamp-on brackets to the proper width creating a tight tension fit
- Use with Stackers and Stackers Flush Mount Panels



Tower Large Clamp-On Mount (STW.CL)


- For use with Clear & Frosted Acrylic and all acoustic EchoScape™ panels
- For use on flat or curved workstation top cap
- Removable adjustable tension mount fits workstation top caps 2.9" – 4.0" in width
- Tower Mount attaches and holds the clamp-on brackets to the proper width creating a tight tension fit
- Use with Stackers and Stackers Flush Mount Panels






Square Mount (SSQ)

- For use with Clear & Frosted Acrylic and 3/8" (9mm) acoustic EchoScape™ Panels
- Permanent mount - Screw down
- For use on a flat or curved panel top cap
- Minimum top cap width - 0.875"
- Kits include 2 or 4 Square Mount kits depending on width of panel
- Use with Stackers and Stackers Flush Mount



Square Adhesive Mount (SSQ.R)

- For use with Clear & Frosted Acrylic and 3/8" (9mm) acoustic EchoScape™ panels
- Removable adhesive strips are used to attach metal plate to flat top cap
- Adhesive mounts and strips can easily be removed with no damage to top cap
- Minimum top cap width - 1.625"
- Kits include 2 or 4 Square Mount kits depending on width of Stacker panel
- Use with Stackers and Stackers Flush Mount




Double Square Mount (SDSQ)

- For use with Stacker Flush Mount for glass workstation panels only
- Clamp can be used on materials that are 0.220" to 0.390" thick material
- Kits include 2 or 3 Double Square Mount



Invisible Mount (IM)

- For use with 3/4" (18mm) acoustic EchoScape™ only
- Permanent mount - Screw down
- For use on a flat workstation top cap only
- Mounting locations on EchoScape™ panel are preset and posts slide into panel for invisible mount
- Minimum top cap width - 0.75"
- Kits include 2 or 4 Invisible Mount kits depending on width of panel



Invisible Adhesive Mount (IM.R)

- For use with 3/4" (18mm) acoustic EchoScape™ only
- For use on a flat top cap
- Removable adhesive strips are used to attach metal plate to top cap
- Adhesive mounts and strips can be easily removed with no damage to top cap
- Mounting locations on EchoScape™ panel are preset and posts slide into panel for invisible mount
- Minimum workstation trim width for Invisible Mount usage - 1.625"
- Kits include 2 or 4 Invisible Mount kits depending on width of panel

